

Trash Compactor Repairs Maintenance Tips:

- **Warning:** To avoid personal injury or even death, always disconnect your appliance from its power source. This is, unplug it or break the connection at the circuit breaker or fuse box. Before you do any troubleshooting or repairs on your appliance. Also because some component may have sharp edges, use caution while working your appliance.
- **Cleaning:** You need to regularly, thoroughly clean the interior of your trash compactor. We recommend that you use a bacterial fighting cleaner and/or degreaser to clean the ram. (The platform that presses down on the garbage) and any other part of the compactor that come into contact with garbage.
- **Odour Control:** Because you put food waste into it, bacteria can grow on the inside of your trash compactor. For temporary odour control between cleaning, spray the interior with a germ-killing deodorant/disinfection. Also replace the filter (if there is one) once or twice a year.